



The Town of Leesburg

Department Of Engineering And Public Works STORM DRAIN MARKER PROGRAM

INSTALLATION INSTRUCTIONS

As easy as 1, 2, 3



1. Clean Surface

Clean the curb where the marker is to be placed. The adhesive surface should be flat, dry and free of any loose debris.



2. Apply Adhesive

Apply a bead of adhesive following the dotted line starting at #1 and then work in to the center.



3. Stick It!

Apply the marker to the curb, pushing down **HARD**. This will force adhesive out around the entire edge. It is important that the entire edge of the marker is sealed to the application surface. Wash hands with hand cleaner then soap and water.

SAFETY PRECAUTIONS:



Safety Notes regarding the adhesive materials: Danger: Extremely flammable. Vapor harmful . Vapors may ignite explosively. Use only in well ventilated area. Keep away from and do not use near heat, sparks, and open flames. Do not smoke. Extinguish or remove from area all sources of ignition during use and until all vapors are gone. Keep container closed when not in use and store at room temperature. Do not swallow or breathe vapor. Can cause respiratory irritation, dizziness, headache, nausea, and unconsciousness. Avoid contact with skin, eyes or clothing. Can cause irritation and burns. **KEEP OUT OF REACH OF CHILDREN.**

Please contact das Manufacturing regarding proper installation technique or special requirements. Address: das Manufacturing, Inc of das 3610 Cinnamon Trace drive Valrico, Florida 33594 Phone 800-549-6024